#### Laminar Flow Flat Plate Convection


Thermal Fluids and Energy Systems Lab

(ME EN 4650)

Prof. Pardyjak

Department of Mechanical Engineering

University of Utah



Based on Prof. M's slides


# Objectives

- Measure the temperature as a distance of length along a heated flat plate using embedded thermocouples
- Calculate the local and average heat transfer coefficients and Nusselt numbers
   & compare with the theoretical predictions,
- Calculate the net heat flux from the surface

### Convective Heat Transfer

#### What we want to know:

- 1.  $Nu = f(x^*, Re, Pr)$
- 2. q'' (heat fluxes)
- 3.  $T_S$  (surface temperatures)



#### What we can measure:

- 1.  $P_{dyn}$ : Pitot-static probe (Bernoulli)
- 2.  $T_s(x)$ : using thermocouples
- 3. q": heat flux from heating element (V and R from a multimeter)
- 4.  $T_{\infty}$ : thermocouples

$$Nu = \frac{hL}{k}$$

$$Re = \frac{U_{\infty} L}{\nu}$$


$$Pr = \frac{\nu}{\alpha}$$

# Nusselt Number Relationships


$$\overline{Nu} = CRe_L^m Pr^n$$

Nusselt Interpretations:


- 1. A non-dimensional temperature gradient at the wall
- 2. Ratio of convective heat transfer to pure conduction (i.e., if the fluid was motionless)



## Flow over a Flat Plate



THE UNIVERSITY OF UTAH




Heat flux (top surface):

$$q_s'' = \frac{P_e}{A_s}$$

We'll assume a uniform heatflux boundary condition

## **Prandtl Number Heated Plate**



$$Pr = \frac{\nu}{\alpha}$$


Here, 
$$Pr = \frac{\nu}{\alpha} > 1$$
 Since  $\frac{\delta}{\delta_t} > 1$ 

This is the case for oils

Pr ~ 1 for gases  $(\delta \sim \delta_t)$ 

Pr < 1 for liquid metals ( $\delta_t > \delta$ )

# Effect of Prandtl Number on Boundary Layer Growth



Heat flux (top surface):

$$q_s'' = \frac{P_e}{A_s}$$

Newton's Law of Cooling:

$$q_s'' = h(x)[T_s - T_\infty]$$


At the wall:  $q_s'' = -k_f \frac{\partial T}{\partial y} \bigg|_{y=0}$ 


Local heat transfer coefficient:


$$h(x) = \frac{q_s''}{[T_s - T_\infty]}$$

Local Nusselt number:

$$Nu_x = \frac{h(x)x}{k_f}$$







Heat flux (top surface):

$$q_s'' = \frac{P_e}{A_s}$$

Newton's Law of Cooling:

$$q_s'' = h(x)[T_s - T_\infty]$$


At the wall:  $q_s'' = -k_f \frac{\partial T}{\partial y} \bigg|_{y=0}$ 

Local heat transfer coefficient:

$$h(x) = \frac{q_s''}{[T_s - T_\infty]}$$

Local Nusselt number:

$$Nu_x = \frac{h(x)x}{k_f}$$




Evaluate  $k_f$  at film temperature

$$T_f = \frac{T_s + T_\infty}{2}$$

Look up or use Matlab script provided on CANVAS

# Flat Plate with Unheated Starting Length




Average heat transfer coefficient:  $\overline{h}_L = \frac{1}{L-\xi} \int_{x=\xi}^{x=L} h(x) dx$ 

Average Nusselt number:

$$\overline{Nu}_L = \frac{\overline{h}_L L}{k_f}$$

THE UNIVERSITY OF UTAH

# Effect of Unheated Starting Length on Average Nusselt Number





# Measurements

Quantity	Symbol	Units	Instrument
Freestream dynamic pressure	$P_{ m dyn}$	mmHg	Pitot-static probe
Plate surface temperature	$T_s(x)$	$^{\circ}\mathrm{C}$	thermocouple
Freestream temperature	$T_{\infty}$	$^{\circ}\mathrm{C}$	thermocouple
Heater voltage	V	VAC	multimeter
Heater resistance	Ω	Ohm	multimeter

# Wind Tunnel


24" x 12" x 12" cross section





# Experimental Apparatus

Heated Flat Plate with an Unheated Starting Length



6 & 12 are on the bottom


For laminar flow:  $Re_L < 5 \times 10^5$  which is ~ 40 m/s

Units in mm The university of utah

13.5


# Photographs of Heated Plate





Assumption of constant heat flux?

# Data Analysis: Measurements



Heat flux from the top surface:  $q_s'' = \frac{P_e}{2A_p} = \frac{V^2}{R2L_hw}$ 

 $P_e$  – total power supplied to heater

Local heat transfer coefficient:  $h(x_i) = \frac{q_s''}{T_s(x_i) - T_\infty}$ 

Average heat transfer coefficient:  $\overline{h}_L = \frac{1}{L_T} \int_{x_1}^{x_{14}} h(x) dx$ 

Use Trapezoidal rule

# Data Analysis: Measurements

Local Nusselt number:  $Nu_x=rac{h(x)x}{k_f}$  Use AirProperties.m script Average Nusselt number:  $\overline{Nu}_L=rac{\overline{h}_L L}{k_f}$ 

# Data Analysis: Theoretical Formulas

(Kays and Crawford, 1993; Ameel, 1997)

#### For Laminar Flow

Local Nusselt number:

$$Nu_{x,\text{th}}(x) = \frac{0.453 Re_x^{1/2} Pr^{1/3}}{\left[1 - (\xi/x)^{3/4}\right]^{1/3}}$$

Local heat transfer coefficient:  $h_{x,\mathrm{th}}(x) = \left(\frac{k_f}{x}\right) N u_{x,\mathrm{th}}(x)$ 

Average heat transfer coefficient:


$$\overline{h}_{L,\text{th}} = 2\left(\frac{\overline{k}_f}{L-\xi}\right) \left(0.453 Re_L^{1/2} Pr^{1/3}\right) \left[1 - \left(\frac{\xi}{L}\right)^{3/4}\right]^{2/3}$$

Average Nusselt Number:

$$\overline{Nu}_{L,\text{th}} = \frac{\overline{h}_{L,\text{th}} L}{\overline{k}_f}$$

Assume all properties are constant and evaluated at the average film temperature

# Data Analysis: Predictions from Theory



#### **Newtons Law of Cooling**

Estimate Heat Flux

given measurements o<u>f surface tempera</u>ture)

$$q_{s, ext{th}}''(x_i) = h_{x, ext{th}}(x_i) \left[T_s(x_i) - T_\infty\right]$$
 Meas

$$q_{s,\text{th}} = \frac{w L_h}{L_T} \int_{x=x_1}^{x=x_N} q_{s,\text{th}}''(x) dx$$

Trapezoidal Rule

Estimate Surface Temperature (given measurements of heat flux)

$$T_{s,\text{th}}(x) = T_{\infty} + \frac{q_s''}{h_{x,\text{th}}(x)}$$

## Effect of Thermal Radiation

Local radiation heat flux (top surface):

$$q_{\rm rad}''(x_i) = \epsilon \, \sigma \left( T_s^4(x_i) - T_\infty^4 \right)$$

Temperature need to be in Kelvin (absolute!)

$$\epsilon = 0.7$$

$$\sigma = 5.6703 \times 10^{-8} (\mathrm{W \, m^{-2} K^{-1}})$$

Now we can plot corrected surface temp


$$T_{s,\text{th}}(x) = T_{\infty} + \frac{q_s'' - q_{\text{rad}}''}{h_{x,\text{th}}(x)}$$

Average Heat Transfer Rate

$$q_{\text{rad},L}'' = \frac{1}{L_T} \int_{x=x_1}^{x=x_N} q_{\text{rad}}''(x) dx$$

Total Heat Transfer Rate:

$$q_{\rm rad,L} = A_{hp} q_{\rm rad,L}^{\prime\prime}$$



Percent radiation lost to the surroundings

$$\frac{q_{\mathrm{rad},L}^{\prime\prime}}{q_s^{\prime\prime}} \cdot 100 \quad \text{~~15\%}$$

#### Data

 No physical lab – data are provided for you on CANVAS under RESOURCES – Experimental Tools: ConvectionData.dat %Thermocouple Number Thermocouple Temp. (C)

% Pbaro = 776-120.6 mmHg

% Tamb = 22.2 oC

% dynamic pressure = 0.1 in H2O

% voltage = 40.03 VAC

% resistance = 157.1 Ohms

1.0 30.8

2.0 33.6

3.0 34.4

4.0 35.8

5.0 38.2

6.0 37.6

7.0 37.9

8.0 39.6

9.0 39.3

10.0 39.7

11.0 40.0

12.0 39.8

13.0 40.9

14.0 40.0

15.0 40.6

16.0 41.0

#### Data

Bernoulli

$$U_{\infty} = \sqrt{2 P_{\rm dyn}/\rho}$$

Thermocouple	Location (mm)	Thermocouple	Location (mm)
1	85	9	153
2	92	10	162
3	102	11	173
4	112	12	173
5	123	13	186
6	123	14	196
7	134	15	209
8	143	16	219

#### Data

 AirProperties.m script provided for computed (Temps in Kelvin, Pressure in Pa, see Appendix)

[rho,mu,k,Cp] = AirProperties(T,P)